

TrueTracker Supported Platforms

v4.3

"February 2013"

Only use official Trimble platform kits with the Trimble AgGPS TrueTracker system. Always ensure you follow the installation instructions and download the latest version on the Partners web site. The AgGPS AutoPilot is supported for installation on the following vehicles.

Hose kit information is available in the instruction manual.

Implements

<i>Type</i>	<i>Models</i>	<i>FmX Platform Kit</i>	<i>FMD Platform Kit</i>	<i>VDB name</i>	<i>VDB location</i>	<i>Minimum Firmware required</i>	<i>Typical Steering Gain</i>	<i>Typical Dead Zone</i>
Rear Coulters	Tracker IV / Tracker III	54067-05	54066-05	Implement - Orthman 1.vdb	Ext	5.23	3-8	30-40
Rear Load Bearing Wheels	Spudnik Planters / Windrowers	54067-11	54066-11	Implement - Rear Steering.vdb	Ext	5.23	6-15	30-40
3-point Articulated	SUNCO AcuraTrak	54067-08	54066-08	Implement - Sideshift Sunco.vdb	Ext	5.23	3-8	30-40
Lateral sideshift / 3 point	Navigator or Sideshifting without potentiometer	54067-08	54066-08	Implement - Sideshift.vdb	Ext	5.23	3-8	30-40
Tongue Steer	ETS Soil Warrior / Harriston planter / Lockwood planter	54067-12	54066-12	Implement - Tongue Steering.vdb	Ext	5.23	6-15	30-40
Generic kit for use with SCV's	All	54067-10	54066-10	Select one above				
H3 Power beyond implement kit	All	54067-20	54066-20	Select one above				
H3 Open Center implement kit	All	54067-21	54066-21	Select one above				